

hama[®]


THE SMART SOLUTION

00
053173

Gigabit Ethernet Adapter

USB 3.0

Gigabit Ethernet-Adapter



Operating Instructions

GB

Bedienungsanleitung

D

Mode d'emploi

F

Instrucciones de uso

E

Руководство по эксплуатации

RUS

Istruzioni per l'uso

I

Gebruiksaanwijzing

NL

Οδηγίες χρήσης

GR

Instrukcja obsługi

PL

Használati útmutató

H

Návod k použití

CZ

Návod na použitie

SK

Manual de instruções

P

Kullanma kılavuzu

TR

Manual de utilizare

RO

Bruksanvisning

S

Pistokelaturi

FIN

Content

1. Packaging contents
2. Installing the driver
 - 2.1 Windows
 - 2.2 Mac OS X
3. Service and Support
4. Recycling Information

1. Packaging contents

- USB 3.0 Gigabit Ethernet adapter
- Driver CD
- Installation instructions


2. Driver Installation

2.1 Windows

Important

- Install the driver before connecting the USB Ethernet adapter to your computer/laptop.

Place the enclosed driver CD into your PC/laptop's CD-ROM drive.



Select the desired language.



Click on "Install Driver" to select the operating system.



Click „Windows“ to start the installation. The driver is then automatically installed.

Restart the operating system after installation is complete. The USB Ethernet adapter can then be plugged into a free USB port and is ready for use.

2.3 Mac OS X

Open the drive folder on the CD by clicking on "Mac OS X" and then run the installation package "AX88179_178A.dmg".

Follow the steps of the installation program and restart the system once installation is complete. The USB Ethernet adapter can then be plugged into a free USB port and is ready for use.

3. Service and Support

Please contact Hama Product Consulting if you have any questions about this product.

Hotline: +49 9091 502-115 (German/English)

Further support information can be found here: www.hama.com

4. Recycling Information

Note on environmental protection:



After the implementation of the European Directive 2002/96/EU and 2006/66/EU in the national legal system, the following applies:

Electric and electronic devices as well as batteries must not be disposed of with household waste. Consumers are obliged by law to return electrical and electronic devices as well as batteries at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilising old devices/Batteries, you are making an important contribution to protecting our environment.

hama®

**Hama GmbH & Co KG
86652 Monheim / Germany
www.hama.com**

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

00053173/06.15